

Sortiment

Č. hlas. destičky / Stimmpate-Nr. / Reeds-No.	Délka / Länge / Length	Šířka / Breite / Width	Tloušťka / Dicke / Thickness	Tón / Ton / Tone	
BB-95	95,0	26,0	6	1E - Dis	Bass - side
BB-90	90,0	26,6	6	1E - Dis	
BB-80	80,0	15,0	6	1E - Fis	
BB-74	74,0	23,8	5	1E - dis	
BB-70	70,0	23,3	5	1E - fis	
BB-68	67,5	23,1	5	1E - fis	
BB-62	62,0	19,0	5	1A - h	
BB-58	58,5	20,5	5	1A - h	
3-59	59,0	16,5	4	1E - E	Treble - side
3-56	56,0	16,5	4	1Ais - e	
3-53	53,5	16,5	4	E - e	
3-52	52,5	16,5	4	E - fis	
3	50,0	16,5	4	E - h	
4	47,5	16,0	4	H - c'	
4/6	47,5	16,0	4	c1 - e1	
4/7	47,5	16,0	4	d - h1	
5	47,5	16,0	4	g - e1	
6	45,0	16,0	4	c1 - e1	
7	43,5	16,0	3,5	d - h1	
7/8	43,5	16,0	3,5	f1 - h1	
7/9	43,5	16,0	3,5	g1 - g2	
8	42,0	16,0	3,5	f1 - h1	
9	40,0	16,0	3,5	g1 - g2	
10	38,5	16,0	3,5	h1 - e2	
11	36,5	16,0	3,5	cis2 - g2	
12	35,0	16,0	3,5	c2 - h2	
12/13	35,0	16,0	3,5	f2 - cis3	
13	33,0	16,0	3,0	f2 - cis3	
14	31,5	16,0	3,0	a2 - f3	
15	30,0	16,0	3,0	h2 - e3	
16	28,5	16,0	3,0	d3 - g3	
17	27,0	16,0	3,0	e3 - a3	
18	25,5	16,0	3,0	e3 - c4	
19	24,5	16,0	2,5	a3 - h3	High octave
20	23,5	16,0	2,5	ais3 - d4	
21	22,5	16,0	2,5	c4 - g4	
22	21,0	16,0	2,5	e4 - g4	
23	20,0	16,0	2,5	cis4 - g4	
24	19,0	16,0	2,5	f4 - cis5	