


Chromatická řada		
+	+	Ms - závaží - Gewicht - Tip
+	+	Sn - závaží - Gewicht - Tip



1C	1C#	1D	1D#	1E	1F	1F#	1G	1G#	1A	1A#	1H	C	C#	D	D#	E	F	F#	G	G#	A	A#	H	c	C#	d	d#	e	f	f#	g	g#	a	a#	h	c ₁	C ₁ #	d ₁	d ₁ #	e ₁	f ₁	f ₁ #	g ₁	g ₁ #	a ₁	a ₁ #	h ₁	c ₂	C ₂ #	d ₂	d ₂ #	e ₂	f ₂	f ₂ #	g ₂	g ₂ #	a ₂	a ₂ #	h ₂	c ₃	C ₃ #	d ₃	d ₃ #	e ₃	f ₃	f ₃ #	g ₃	g ₃ #	a ₃	a ₃ #	h ₃	c ₄	C ₄ #	d ₄	d ₄ #	e ₄	f ₄	f ₄ #	g ₄	g ₄ #	a ₄	a ₄ #	h ₄	c ₅	C ₅ #	d ₅
4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90
32,703 Hz	34,648 Hz	36,708 Hz	38,891 Hz	41,203 Hz	43,654 Hz	46,249 Hz	48,999 Hz	51,913 Hz	55 Hz	58,27 Hz	61,735 Hz	65,406 Hz	69,296 Hz	73,416 Hz	77,782 Hz	82,407 Hz	87,307 Hz	92,499 Hz	97,999 Hz	103,826 Hz	110 Hz	116,541 Hz	123,471 Hz	130,813 Hz	138,591 Hz	146,832 Hz	155,563 Hz	164,814 Hz	174,614 Hz	184,997 Hz	195,998 Hz	207,652 Hz	220 Hz	233,082 Hz	246,942 Hz	261,626 Hz	277,183 Hz	293,665 Hz	311,127 Hz	329,628 Hz	349,228 Hz	369,994 Hz	391,995 Hz	415,305 Hz	440 Hz	466,164 Hz	493,883 Hz	523,251 Hz	544,365 Hz	587,330 Hz	622,254 Hz	659,255 Hz	698,456 Hz	739,989 Hz	783,991 Hz	830,609 Hz	880 Hz	932,328 Hz	987,767 Hz	1046,502 Hz	1108,731 Hz	1174,659 Hz	1244,508 Hz	1318,510 Hz	1396,913 Hz	1479,978 Hz	1567,982 Hz	1661,219 Hz	1760 Hz	1864,655 Hz	1975,533 Hz	2093,005 Hz	2217,461 Hz	2349,318 Hz	2486,016 Hz	2637,020 Hz	2793,826 Hz	2959,955 Hz	3135,963 Hz	3322,438 Hz	3520 Hz	3729,310 Hz	3951,066 Hz	4186,009 Hz	4434,922 Hz	4698,600 Hz